


CUT ALONG THIS LINE

CUT ALONG THIS LINE

CUT ALONG THIS LINE



TOP CABINET TEMPLATE

NOTE: READ AND FOLLOW ALL DIRECTIONS IN THE INSTALLATION INSTRUCTIONS BEFORE PROCEEDING WITH THE TOP CABINET TEMPLATE.

This template is used to locate the Power Cord Clearance Hole, Cabinet Mounting Holes, and the Vertical Exhaust Cutout.

1. Determine whether your cabinet has a recessed area (Fig. 1) or a smooth, flat bottom (Fig. 3). If your cabinet has a flat bottom, tape the template onto the bottom surface of the cabinet (Fig. 4), then proceed to Step 3.
2. If your cabinet is recessed, cut the edges of the template to fit the recessed bottom of the cabinet. It is important that the edges of the cabinets permit level installation of the oven.

Follow directions below for cutting and mounting:

RECOMMENDED CUTTING PROCEDURE
Measure cabinet thickness of sides A and C, and back B. Cut the edge of the template to allow for cabinet thickness (guidelines are marked in 1/4" increments for your convenience).

NOTE: A small bracket or glue block may be present on some cabinets between the overhang and underside of the cabinet bottom. Cut the template to fit around the bracket or block so that the template lies flat against the bottom of the cabinet.

Tape the Cabinet to the underside of the top cabinet within the recessed area (Fig. 2)

NOTE: Make sure the rear of the template touches either the back of the wall (for flat-bottom cabinets) or the back of the recessed area (for recessed bottom cabinets) after cutting the edges of the template.

3. Drill 3/8" diameter holes at positions A, B, and C.
CAUTION Always wear safety goggles when drilling holes in the cabinet bottom.
4. Cut a 2" diameter hole at position D for the Power Cord. If drilling into a metal cabinet, use the Nylon Grommet (listed in the Parts Included section of the Installation Instructions) to surround the opening of the hole to protect the cord from damage.
5. FOR VERTICAL EXHAUST ONLY (Skip for Horizontal or Recirculation Exhaust): Cut out shaded area labeled E in the cabinet bottom for the Vertical (Outside) Exhaust location.
6. Remove the Top Cabinet Template.
7. For recessed cabinets: cut out 2 filler blocks out of scrap wood the sizes of shaded areas F and G (~2-9/16" x 3"). These blocks must have a thickness equal to the depth of the cabinet recess. Drill 3/8" diameter holes in the blocks to line up with holes A and C. The blocks should be level with the bottom edge of the cabinet frame (Fig. 5)
8. Return and proceed with the Installation Instructions.

